












































LAY5 Push Button & Indicator Series

Push button& Indicator	Description	Contact	Circuit	Color	Type
LAY5-EC42					
	Mushroom head	N/O		Black Φ40	LAY5-EC21
				Green Φ40	LAY5-EC31
		N/C		Red Φ30	LAY5-EC442
				Red Φ40	LAY5-EC42
LAY5-ES542					
	Turn to release	N/C		Red Φ30	LAY5-ES442
				Red Φ40	LAY5-ES542
				Red Φ60	LAY5-ES642
LAY5-ET42					
	Push-pull Red	N/C		Green Φ40	LAY5-ET44
				Black Φ60	LAY5-EX42
LAY5-ES142					
	Rey release (Key n° 445)	N/C		Red Φ30	LAY5-ES742
				Red Φ40	LAY5-ES142
	Turn to release Rey release (Key n° 445)	N/O + N/C		Red Φ40	LAY5-ES8445
				Red	LAY5-ES9445
LAY5-ED21					
	2 Position stay put	N/O		Standard handle	LAY5-ED21
		N/O + N/C		Standard handle	LAY5-ED25

Push button& Indicator	Description	Contact	Circuit	Color	Type
LAY5-ED33					
	3 Position stay put	N/O + N/C		Standard handle	LAY5-ED33
	2 Position 1 spring return from right to left	N/O		Standard handle	LAY5-ED43
	3 Position 2 spring return to centre	N/O + N/C		Standard handle	LAY5-ED45
		N/O + N/C		Standard handle	LAY5-ED53
LAY5-EJ21					
	2 Position stay put	N/O		Long handle	LAY5-EJ21
		N/O + N/C		Long handle	LAY5-EJ25
LAY5-EJ33					
	3 Position stay put	N/O + N/C		Long handle	LAY5-EJ33
	2 Position 1 spring return from right to left	N/O		Long handle	LAY5-EJ41
	3 Position 2 spring return to centre	N/O + N/C		Long handle	LAY5-EJ45
		N/O + N/C		Long handle	LAY5-EJ55

Push button& Indicator	Description	Contact	Circuit	Color	Type
LAY5-EG21					
	3 Position key stay put	N/O		LH position	LAY5-EG21
		N/O + N/C		LH position	LAY5-EG25
	3 Position key 2 spring return to centre	N/O + N/C		LH and RH position	LAY5-EG45
		N/O		LH and RH position	LAY5-EG41
LAY5-EG33					
	3 Position key stay put	N/O + N/C		Centre position	LAY5-EG33
	3 Position key 2 spring return to centre	N/O + N/C		LH and RH position	LAY5-EG51
LAY5-EL8325					
	1 flush green pushbutton 1 flush red pushbutton Unmarked	N/O + N/C		Green	LAY5-EL8325
				Red	
LAY5-EL8425					
	1 flush green pushbutton 1 flush red pushbutton marked IP40	N/O + N/C		Green I	LAY5-EL8425
				Red O	
LAY5-EL9325					
	1 flush green pushbutton 1 flush red pushbutton (Attransparent silica gel cover)Unmarked IP65	N/O + N/C		Green I	LAY5-EL9325
				Red O	